EK INTERNATIONAL PRODUCTS
eip.se

Ändring av kapacitet och noggrannhet på bordsvåg VT30-5, VT15-2, VT6-1

Instruktion för ändring av kapacitet och noggrannhet:

1. Tryck på nollställningsknappen (ZERO) en gång under uppstartens självtest, tryck sedan två gånger på enhetsknappen (UNIT) och därefter ytterligare en gång på nollställningsknappen (ZERO). Displayen visar då `f=30` (vilket indikerar en maximal belastning på 30 kg).
2. Tryck på nollställningsknappen (ZERO) för att välja önskat mätområde. Du kan välja mellan 3 kg, 6 kg, 15 kg eller 30 kg.
3. Tryck sedan på styck räkningsknappen (PCS) för att visa `D=5` (vilket indikerar ett skaldelningsvärde på 5 g).
   Tryck på nollställningsknappen (ZERO) för att ändra skaldelningsvärde efter behov. Alternativen som finns är 0,5 g, 1 g, 2 g eller 5 g.

Alternativ som kan väljas med ovan instruktion:	
Kapacitet	**Noggrannhet**
30kg	**5 gram**
15kg	**2 gram**
6kg	**1 gram**
3kg	**0,5 gram**

English text:
Range adjustment procedure:
1. During the startup self-test, press the zero button once, press the unit button twice, and then press the zero button once again; the display will show f=30 (indicating a full load of 30 kg).
2. Pressing the zero button allows you to select different measurement ranges as needed: 3 kg, 6 kg, 15 kg, or 30 kg.
3. Then, press the PCS key to display D=5 (indicating a indexing value of 5g); press the ZERO key to select different indexing values as needed, with options of 1g,2g,5g, or 10g.

